

- Recommend wood studs
- Blocking can span over the existing studs or in between existing studs
- If metal studs, make sure the blocking spans the metal studs



