



Expanded Metal Locker Assembly Guide

SMS-05-V39-U




1 WIDE




3 WIDE SINGLE

TIER




1 WIDE




3 WIDE DOUBLE

TIER



1 WIDE



3 WIDE TRIPLE

TIER

General Instructions

1. Check material received against the packing list. First check the number of packages received and then check the contents of each package.
2. Check material received for damage. If damage has occurred, secure a "damage notation" from the carrier.
3. Identify each part as it is unpacked and put like parts together as close as possible to the working area in which they are to be assembled.
4. Be careful to use the correct hardware as specified in the assembly instructions.
5. Items with suffix (xx) are available options.


CAUTION

IN THE INTEREST OF SAFETY, ALL LOCKERS MUST BE SECURELY ANCHORED TO THE FLOOR AND/OR WALL. FOR SAFETY, HANDLE ALL COMPONENTS CAREFULLY AND WEAR WORK-GLOVES WHEN ASSEMBLING LOCKERS. INSTALL ALL UNITS PLUMB AND TIGHTEN ALL HARDWARE SECURELY. RETAIN INSTRUCTIONS FOR FUTURE REFERENCE.



PACKAGE CONTENTS

REF. NO.	DESCRIPTION	PART NO.	1-WIDE QUANTITY			3-WIDE QUANTITY		
			1-TIER	2-TIER	3-TIER	1-TIER	2-TIER	3-TIER
①	REAR PANEL	KRww72-18	1	1	1	3	3	3
②	RIGHT/LEFT SIDE PANEL	KPdd72-DP16	2	2	2	4	4	4
③	TOP/BOTTOM SHELF	KSwwdd-16	2	3	4	6	9	12
④	HAT SHELF	KHwwdd-16	1	-	-	3	-	-
⑤	SINGLE CEILING HOOK	H5K	2	4	-	6	12	-
⑥	DOUBLE CEILING HOOK	H7K	1	2	3	3	6	9
xx⑦	COAT ROD BRACKET	xxTRH200	xx2	xx4	-	xx6	xx12	-
xx⑧	COAT ROD	xxKCRww	xx1	xx2	-	xx3	xx6	-
⑨	DOOR FRAME ASSEMBLY	AKDFww78-†DP	1	1	1	3	3	3
x⑩	DOOR	AKDww72-†DP	1	2	3	3	6	9
x⑪	RECESSED HANDLE S.S.	TBECK2	1	2	3	3	6	9
x⑫	LOCK CHANNEL	KLhh-†	1	2	3	3	6	9
x⑬	CHANNEL STOP	CS002	2	4	6	6	12	18
x⑭	NYLON LATCH	DLB100B	2	4	6	9	12	18
x⑮	SPRING	LS100	2	4	6	9	12	18
x⑯	LOCK BRACKET	SLB101L	1	2	3	3	6	9
x⑰	PLASTIC LIFTER	LC100B	1	2	3	3	6	9
⑱	REAR LEG	KLG	2	2	2	2	2	2
x⑲	BUMPER	KDB300	3	4	6	9	12	18
xxx⑳	NUMBER PLATE	NPH	1	2	3	3	6	9
㉑	NUMBER PLATE RIVET	RV101	2	4	6	6	12	18
㉒	1/2" SLOTLESS BOLT	MBT202	62	74	70	134	166	188
㉓	HEX NUT	N201	60	70	64	128	154	170
㉔	ESCUTCHEON PLATE	RPE100	1	2	3	3	6	9
㉕	HI-DOME CAP NUT	N110	2	4	6	6	12	18
x㉖	RIVET (HANDLE)	RV102	1	2	3	3	6	9
x㉗	RIVET (HINGE)	RV102	7	8	9	21	24	27



Single Tier
KD Locker

PART NUMBER SUFFIX SHOWS WIDTH, DEPTH, HEIGHT AND TIER. CUSTOMER TO SPECIFY.

NOTE:

FOR OPTIONAL INDIVIDUAL SLOPE TOPS,
SEE SUPPLEMENTAL INSTRUCTION SHEET NO. ASY-H-KIST-A.

FOR OPTIONAL 6" HIGH CLOSED METAL BASE,
SEE SUPPLEMENTAL INSTRUCTION SHEET NO. ASY-H-KIST-B.

x SHIPS PRE-HUNG IN DOOR FRAME ASSEMBLY. ⑨


xx OPTIONAL ITEM

PART NO. LEGEND:

ww = WIDTH
dd = DEPTH
hh = HEIGHT (FRAME)
† = TIER
V = VENTILATED

TOOLS REQUIRED: 3/8" NUT DRIVER (3/8" SOCKET MAY BE SUBSTITUTED)





COAT ROD (KCR_{ww}) & COAT ROD BRACKETS (TRH 200) ARE OPTIONAL.

HALLOWELL MAKES EVERY EFFORT TO ENSURE THAT ALL UNITS SHIP COMPLETE; HOWEVER, SHOULD YOUR UNIT CONTAIN MISSING OR DAMAGED PARTS, REPLACEMENTS MAY BE OBTAINED FROM HALLOWELL. TO OBTAIN PARTS, FOLLOW THESE INSTRUCTIONS.

PLEASE PROVIDE THE FOLLOW INFORMATION:

MODEL NUMBER

PURCHASE DATE

DESCRIPTION OF PART(S) NEEDED & PART NUMBER(S) AS SHOWN IN PARTS LIST

COMPANY NAME & CONTACT PERSON

COLOR

WHERE THE PRODUCT WAS PURCHASED FROM

IF REQUESTING PARTS BY TELEPHONE, ASK FOR CUSTOMER SERVICE & PROVIDE THE ABOVE INFORMATION.



